

	Service Period Y Checked	NOTE: THIS SERVICE CHECK IS BEST TO BE PERFORMED BY A TRADESPERSON Eg: Mechanic, engineer, builder, etc	Document Date: 27/10/2023. Every year check for new service document updates at www.pilatesequip.com/instructions
		If you don't understand an instruction, please contact Pilatesequip™ for a clarification	Document number: HIGHBARREL 27102023
		HIGH BARREL (use for Pilatesequip™ equipment only)	Daily
			Weekly
			Monthly
		How to fix	Quarterly
1	Q	Check that barrel slides back and forth smoothly	Remove Barrel from Ladder Frame and clean Slides and Runners
2	Q	Check barrel adjustment Black Adjusting Knobs or screw/wing nuts, spin freely	Replace
3	Q	Check timber frame structure has no cracks	Contact Pilatesequip™ with photos
4	D	Clean all vinyl upholstery daily, as a minimum. Use a mixture of water and some ordinary mild "Sunlight Pure Soap", cut into little flakes and placed in a spray bottle. Clean with a towel, cloth or paper towel. NOTE: Don't use other products such as chemicals, bleach, tea tree or eucalyptus oils, alcohol wipes or methylated spirits, or detergents- as they deteriorate vinyl. Human sweat also causes vinyl deterioration. The vinyl has an antibacterial coating and doesn't need harsh cleaners.	See equipment instructions
5	Q	Check Seat upholstery for damage	Recover - Call local upholsterer
6	Q	Check Warning Sticker isn't worn or removed	Replace